



1. Make 2 pieces
2. 1 Right and 1 left
3. Color side is outside
4. Outside of LH Shown

Steps

1. Fit Bare frame to Car
2. Fold all four sides in 180 degrees.
3. Inside edges will be 5/8" offset.
4. Mark outside perimeter of frame and rubber nose strip.
5. Sew at line around curtain frame.
6. Trial fit on car to establish bottom trim line.
7. Tack Sew @ 1/4" above bottom trim line
8. Trim 3 Edges for final 1/4" edge reveal Top, Front, Rear
9. Trim bottom at trim line
10. Sew 4 sides
11. Bind all around 1/4" binding
12. Fit to frame
13. Sew inside corners 4 places.
14. Turn in 1/2" into window pocket.
15. Install front window piece
16. Install window channel. This traps front window piece toward outside.
17. Install rear window piece
18. Install front and rear brackets.