

LUCAS

Spares List No.

EQUIPMENT & SPARE PARTS

N. V. S. 1532
16-7-58

M.G.
Series M.G.A. Twin Cam
(Later information to CCE 900G)

SPARE PARTS

Battery (2 off)	SG9E		LAMPS		
Coil, ignition	HA12	45054K	Fog (Optional)	SFT576	55128B
Control box	RB106-2	37182H	Head, RHD, dip left	F700	51344B
Distributor	DM2	40510A	Head, LHD, dip right	F700	51345D
Flasher unit	FL5	35010A	Head, export Europe (not France)	F700	51346B
Flasher relay	DB10	33117D	Head, export France	F700EF	51411B
Fuse box	SF6	033239	Head, export U.S.A.	F700	51467B
Generator	C39PV-2	22295A	Head, export N. America (Except U.S.A.)	F700	51533D
§ Brush set		227305	Number plate illumination 467-2		53093H
§ Bracket or frame, commutator		end *54210008	Side & Flasher	539	52236A
§ Bushing, bearing		227818	Stop, tail & Flasher	549	53330D
§ Oiler		227914	Maplight cover		573914
§ Springs, set, brush tension		228159	Maplight glass		573915
§ Bearing, drive end		189307	Maplight gasket		573916
§ Bracket or frame, drive end		*54210774	Mirror (alternative)		
§ Plate, bearing		220202	Right Hand	406/1/29A	062587
§ Washer, dished, oil retain-			Left Hand	406/1/41A	062590
§ ing		220421	Relay, foglamp (Export N. America)	SB40-1	33169B
§ Washer, corrugated, bearing		158730	Starting motor	M35G-1	25022M
§ Nut, shaft		198800	Switches		
§ Washer, 7/16" shakeproof		185085	Dipper	FS22-1	31284A
§ Armature		227693	Flasher	TPS1	31250H
§ Retainer, bearing ring		227631	Knob		311097
§ Collar, drive end bearing		227532	Foglamp	PS7	31515A
§ Collar, distance, commutator			Knob		312866
§ end		164736	Ignition	S45	31449E
§ Field coils		227291	Lighting	PPG1	31251D
§ Terminal		227625	Knob		316154
§ Insulating, tube, terminal (1 yard-length)		857692	Panel rheostat	CHR1	78311A
§ Belt, through 1/4" B.S.F.		228336	Knob		768945
§ Sundry parts set		227726			
Horn, low note	WT618	69046F			
Horn, high note (Optional)	WT618	69047F			
Horn Push	HP19	76205D			

Continued..

Continued...

JOSEPH LUCAS LTD · BIRMINGHAM 18 · ENGLAND

Series M.G.A. Twin Cam (Cont'd)

Switches (cont'd)		
Map Light	PS7	31515A
Knob		316102
Starting motor	ST19-2	76423A
Coupling		764428
Stop lamp	HL2	31082E
Windshield wiper	PS7	31515A
Knob		312865
Warning light (Flasher)	WL13	38132A
Windshield wiper		
Motor	DR2	75297B
Wheelbox		72674A
Crosshead & Rack		743221
Outer casing, motor to wheelbox		743664
Outer casing, w/box to w/box		743665
Outer casing, short, w/box		740746
Grommet		740811
Ferrule, outer casing		740715
Arm LHD		745083
Arm RHD		745082
Blade		737910

GIRLING EQUIPMENT

Clutch Hydraulic Equipment	
Master cylinder	3112254W
Slave Cylinder	3010202W
High Pressure Hose	3700614W

§ Recommended Spares for Stock

- RHD Right Hand Drive
- LHD Left Hand Drive