



A30318

SERVICE PARTS LIST

THE MGA 1600

Item No.	DESCRIPTION	Commencing (C) 68851		Quantity	MODIFICATIONS		REMARKS
		Part Number	Illus. No.		New Part Number	Change Point	
	<b>CHASSIS FRAME</b>						
1	Frame—chassis	AHH5950	1	1	AHH6131	Com. (C) 100352	AHH5950 not available; use AHH6131 ] Standard model
2	Frame—chassis			1	AHH5708	Com. (C) 91240	
3	Plate assembly—tocboard support	AHH5293	2	1			] All round disc brakes model
4	Screw—tocboard plate to goal post	HPZ0406	3	9	HPZ0406		
5	Washer—spring screw	LWZ204	4	9			HPZ0406 not available; use HPZ0406
6	Washer—plain—screw	PWZ104	5	9			
7	Coverplate—goal post—R/H	AHH5343		1			
8	Coverplate—goal post—L/H	AHH5344	6	1			
9	Seal—coverplate lower (felt)	AHH5345	7	2			
10	Seal—coverplate upper (felt)	AHH5346	8	2			
11	Screw—coverplate to goal post	CTZ803	9	6			
12	Screw—coverplate to goal post stay	PTZ1003	10	8			
13	Screw—coverplate to goal post stay	PTZ1005	11	2			
14	Washer—plain—screw	PWZ203	12	2			
15	<b>Extension assembly (front)</b>	AHH5024	13	1			
16	Screw—extension to frame bracket	HPZ0606	14	8			
17	Nut—screw	FNZ106	15	8			
18	Washer—spring—screw	LWZ206	16	8			
19	<b>Bracket assembly—bumper support—R/H</b>	AHH5139		1			
20	<b>Bracket assembly—bumper support—L/H</b>	AHH5140		1			
21	Screw—bracket assembly to front extension	HNS0506	18	6			
22	Nut—screw	FNZ105	19	6			
23	Washer—spring—screw	LWZ205	20	6			
24	Nut—rebound strap spindle	FNZ106	21	2			
25	Washer—spring—nut	LWZ206	22	2			
26	Washer—plain—nut	PWZ206	23	2			
27	Bracket assembly—abutment (starter switch)				AHH5809	Com. (C) 91240	All round disc brakes model

SERVICE PARTS LIST

THE MGA 1600

Item No.	DESCRIPTION	Commencing (C) 68851		Quantity	MODIFICATIONS		REMARKS
		Part Number	Illus. No.		New Part Number	Change Point	
<b>BODY MOUNTING</b>							
1	Packing—front extension support bracket .....	AHH5173	24	2			
2	Packing—front door post .....	AHH5174	25	2			
3	Packing—shut pillar body mounting bracket .....	AHH5175	26	2			
4	Packing—rear body mounting bracket .....	AHH5176	27	2			
5	Packing—cross bar cover plate .....	AHH5177	28	1			
6	Packing—cross bar cover plate .....			1	AHH5781	Com. (C) 91240	Standard model All round disc brakes model
7	Packing—frame goal post upright (outer) .....	AHH5178	29	2			
8	Sealing strip—body/front frame side (rubber) .....	AHH5408	30	2			
9	Sealing strip—body/rear frame side (rubber) .....	AHH5409	31	2			
10	Screw—body .....	HZS0508	32	10			
11	Washer—spring—screw .....	LWZ205	33	10			
12	Washer—plain—screw .....	PWZ205	34	10			
13	Screw—body to goal post cross-bar .....	HZS0506	35	3			
14	Screw—body to goal post cross-bar end .....	HZS0508	36	2			
15	Washer—spring—screw .....	LWZ205	37	5			
16	Washer—plain—screw .....	PWZ205	38	5			
17	Screw—body to shut pillar front/rear brackets .....	HZS0508	39	8			
18	Screw—body to shut pillar .....	HZS0510	40	2			
19	Washer—spring—screw .....	LWZ205	41	10			
20	Washer—plain large—screw .....	PWZ205	42	10			
21	Washer—plain small—screw .....	PWZ105	43	8			
22	Nut—body to front/rear frame bracket .....	FNZ105	44	8			
23	Screw—body to 4th cross-member .....	HZS0506	45	2			
24	Washer—spring—screw .....	LWZ205	46	2			
25	Washer—plain—screw .....	PWZ206	47	2			
26	Rubber—body to cross-bar sealing .....	AHH5528	48	2			
27	Felt—bonnet sealing .....	AHH5458	49	1			