



A2969

Item No.	DESCRIPTION	Commencing (C) 501		Qty. per Veh.	MODIFICATIONS		REMARKS
		Part Number	Illus. No.		New Part Number	Change Point	
	CLUTCH						
	CLUTCH PEDAL AND LINKAGE						
1	Pedal—clutch RHD	AHH5694	1	1			
2	Pedal—clutch LHD	AHH5696	1	1			
3	Bush	185794	2	1			
4	Pad for pedal (rubber)	AHH5100	3	1			
5	Spring—pedal pull-off	130154	4	1			
6	Pin—clevis	CLZ0515	5	1			
7	Washer for pin (plain)	PWZ105	6	1			
	MASTER CYLINDER ASSEMBLY						
8	Master cylinder assembly	BHA4072	1	1			
9	Body	17H4476	7	1			
10	Cap—filler	7H4379	8	1			
11	Gasket	7H4726	9	1			
12	Seal—valve	7H4750	10	1			
13	Stem—valve	7H4751	11	1			
14	Spacer—valve	17H4132	12	1			
15	Plunger	17H4510	13	1	17H4755		17H4510 not available use 17H4755 and 17H4827
16	Seal—plunger	7H4976	14	1			
17	Spring	7H4944	15	1			
18	Push-rod	17H4544	16	1			
19	Cover—dust	7H4757	17	1			
20	Retainer—spring	17H4827	18	1			Correction was 7H4755
21	Washer—retaining	7H4756	19	1			
22	Circlip	7H4451	20	1			
23	Washer (spring)	7H4752	21	1			
24	Seal—taper end	17H4509	22	1			
25	Bolt fixing cylinder	HZS0510	23	2			
26	Nut for bolt	LNZ205	24	2			
27	Washer for nut (plain)	PWZ105	25	2			
28	Pipe—master cylinder to hose RHD	AHH5822	26	1			
29	Pipe—master cylinder to hose LHD	AHH5824	1	1			
30	Hose—clutch	11B5086	27	1			
31	Locknut for hose	BCA4092	28	1			
32	Washer (shakeproof)	LWN606	29	1			Correction was 2K7131
33	Gasket—hose to pipe	3H876	30	1			
34	Clip—clutch pipe to master cylinder base plate RHD	PCR0311	31	1			
35	Clip—clutch pipe to bulkhead LHD	PCR0311	2	1			
36	Service kit for master cylinder	8G8219	1	1			
37	Seal—plunger		1	1			
38	Seal—valve		1	1			
39	Washer—spring		1	1			
40	Seal—taper end		1	1			
41	Cover—dust		1	1			
42	Circlip		1	1			
43	Gasket—filler cap		1	1			

SERVICE PARTS LIST

THE MG Series MGA TWIN CAM

Item No.	DESCRIPTION	Commencing (C) 501		Qty. per Veh.	MODIFICATIONS		REMARKS
		Part Number	Illus. No.		New Part Number	Change Point	
	SLAVE CYLINDER ASSEMBLY						
1	Slave cylinder assembly.....	BHA4073		1			
2	Body	N.S.P.	32	1			
3	Seal	17H4712	23	1			
4	Plunger	N.S.P.	34	1			Correction was 17H4327
5	Cover—dust	17H4010	35	1			
6	Spring	7H4970	36	1			
7	Screw—bleed	7H4973	37	1			
8	Ball—bleed screw	7H4030	38	1			
9	Cap—bleed screw dust	7H4419	39	1			
10	Circlip	17H4011	40	1			
11	Push rod—slave cylinder	BHA4074	41	1			
12	Locknut—master cylinder push rod	FNZ205	42	1			
13	Fork end—master cylinder push rod	FEZ105	43	1			
14	Banjo	3H868	44	1			
15	Bolt for banjo	2F5276	45	1			
16	Gasket for banjo	17H4021	46	1			
17	Gasket for banjo	17H4179	47	1			
18	Bolt—fixing cylinder	AHH5762	48	2			
19	Washer for bolt (spring)	LWZ206	49	2			
20	Clevis pin—slave cylinder to clutch fork	CLZ0517		1			
21	Washer for clevis pin (plain)	PWZ105		1			
22	Service kit for slave cylinder.....	8G8249		1			
23	Seal			1			
24	Cover—dust			1			
25	Ball—bleed screw			1			
26	Cap—bleed screw dust			1			
27	Circlip			1			