

CONFIDENTIAL

MG / 358

SERVICE MEMORANDUM

MGF/68

24 March 1961

SCRATCHES ON FLEXIBLE BACK-LIGHTS

MGA

MGA 1600

MGA 'Twin Cam'

If the surface of the transparent flexible sheet is not too badly damaged, surface hair scratches may be removed in the following manner:

Using a soft sponge, wash with soap and water, rinse with clean water, and dry.

A smear of hard wax polish should then be applied with a soft moistened cloth, to give a veneer of wax and fill the scratches.

Finally polish with a soft duster.